



www.boatlanes.com

Humminbird Directions:

To transfer the information from your new BOATLANES Sam Rayburn/Toledo Bend MMC card to your Humminbird GPS Unit: **Begin by inserting the card into your Humminbird Unit card slot.**

Your Humminbird GPS Unit makes it very easy to access the BOATLANES Trails. Once you insert the BOATLANES MMC card into your GPS; Wait for it to load (*a few seconds*) and the trails should appear clearly marked on your GPS screen.

CHANGING “VISIBILITY” SETTINGS: If the BOATLANES TRAILS appear **too small**, as a **dotted line** or are **too light for clear navigation** you can **use the following steps** to change the settings so they will appear darker, as solid lines and/or Are a more visible color for navigation:

1. There is a Menu Options Bar across the top of your GPS Screen; Arrow over Right to highlight the “NAV” section
2. Arrow down the drop-down menu below “NAV” to highlight “SAVED TRACKS”
3. Arrow over Right from “SAVED TRACKS” menu options to select “DEFAULT”
4. On this screen make sure that you see the “VISIBILITY” Option is Marked “VISIBLE”
5. Arrow down to highlight “STYLE” and use your arrow keys to scroll through the options until you can select a **SOLID LINE**
6. Next, Arrow to “COLOR” and as with “STYLE” scroll through options to select the color you prefer (*Most Visible on Screen for Navigation—Probably a darker color will show up best*)
7. Once you have made these changes press “SAVE”; Now press “EXIT” Key to back out of this and go back to the map screen that contains the BOATLANES Trails; They should now reflect the newly implemented changes and you should be able to ...*Navigate the Boat Lanes Like A Pro!*

Important Note: On Sam Rayburn the Way Points mark the edges of “Stump” Fields. *You can check the lake water levels on our website at <http://boatlanes.com/boatlanesresources.html#lakeresources> As water levels do fluctuate. Please See our **WARNINGS AND DISCLAIMERS PAGE FOR MORE ABOUT SAFE GPS NAVIGATION.***

“Unlocking a Pointer” is the most efficient way to navigate using your GPS because it allows you to point your boat in the direction of the next GPS waypoint and gives you visual reference of your direction.

In order to utilize **COURSE PROJECTION LINE** (“Unlock a Pointer”):

- 1) Highlight “Course Projection Line” on the Navigation main menu
- 2) Use the LEFT or RIGHT 4-WAY Cursor Control keys to change the Course Projection Line setting (Hidden, Visible, Default = Visible).

Thank you for your business!